

FILTERBUY®

AIRMEGA 150 (AP-1019C)

INSTALLATION INSTRUCTIONS

Filter Types: Pre-Filter, Deodorization Filter, Green True HEPA™ Filter

INSTALLATION STEPS:

1 TURN OFF & UNPLUG THE UNIT:

- Always ensure the device is powered down and unplugged before maintenance.

2 OPEN THE FRONT COVER:

- Gently pull the top part of the front cover to access the filters.

3 REMOVE EXISTING FILTERS:

- Press down on the top clip of the pre-filter and pull it out.
- Remove the deodorization filter.
- Extract the Green True HEPA™ filter.

4 PREPARE NEW FILTERS:

- Unwrap all new filters from their plastic packaging.
- **Ensure the filters are oriented correctly:** the green side of the Green True HEPA™ filter should face the deodorization filter, and the white side should face the fan.

5 INSTALL NEW FILTERS IN THE FOLLOWING ORDER:

- **Green True HEPA™ Filter:** Insert first, with the correct orientation.
- **Deodorization Filter:** Place it in front of the Green True HEPA™ filter.
- **Pre-Filter:** Attach last, ensuring it's secured properly.

6 CLOSE THE FRONT COVER:

- Align and press the cover back into place until it fits securely.

7 RESET THE FILTER INDICATOR:

- After replacing the filters, press and hold the filter reset button for 2 seconds until the indicator light turns off.

Note: Regularly clean the pre-filter and replace the deodorization and Green True HEPA™ filters as indicated by the filter replacement indicator.