

FILTERBUY®

AIRMEGA AP-1216L

INSTALLATION INSTRUCTIONS

Filter Types: Pre-Filter, Odor (Deodorization) Filter, True HEPA Filter

INSTALLATION STEPS:

1**TURN OFF & UNPLUG THE UNIT:**

- Ensure the air purifier is powered down and unplugged.

2**OPEN THE FRONT COVER:**

- Pull the upper part of the front cover to access the filters.

3**REMOVE USED FILTERS:**

- Press down on the top clip of the pre-filter and pull it out carefully.
- Remove the odor filter.
- Take out the True HEPA filter.

4**PREPARE NEW FILTERS:**

- Unwrap each filter from its plastic packaging.
- **Ensure correct orientation:** the front side of each filter should face outward.

5**INSTALL NEW FILTERS IN THE FOLLOWING ORDER:**

- **True HEPA Filter:** Insert first, ensuring it fits securely.
- **Odor Filter:** Place it in front of the True HEPA filter.
- **Pre-Filter:** Attach last, making sure it's firmly in place by pushing the grip.

6**CLOSE THE FRONT COVER:**

- Align and press the cover back until it clicks into place.

7**RESET THE FILTER INDICATOR:**

- After replacing the filters, press and hold the filter reset button until the indicator light turns off.

Note: Regular maintenance includes cleaning the pre-filter every 2-4 weeks and replacing the odor and True HEPA filters as indicated by the filter replacement indicators.