

**FILTERBUY®**

# AIRMEGA AP-1512HH

## INSTALLATION INSTRUCTIONS

**Filter Types:** Pre-Filter, Deodorization Filter, True HEPA Filter

### INSTALLATION STEPS:

**1****TURN OFF & UNPLUG THE UNIT:**

- Ensure the air purifier is powered down and unplugged for safety.

**2****OPEN THE FRONT PANEL:**

- Gently pull the upper part of the front cover to access the filters.

**3****REMOVE OLD FILTERS:**

- Take out the pre-filter.
- Remove the deodorization filter.
- Extract the True HEPA filter.

**4****PREPARE NEW FILTERS:**

- Unwrap the new filters from their packaging.
- Ensure each filter is free from plastic coverings before installation.

**5****INSTALL NEW FILTERS IN THE FOLLOWING ORDER:**

- **True HEPA Filter:** Insert first, ensuring the correct orientation.
- **Deodorization Filter:** Place it in front of the True HEPA filter.
- **Pre-Filter:** Attach last, securing it properly.

**6****CLOSE THE FRONT PANEL:**

- Align it back into position and press until it clicks securely.

**7****RESET THE FILTER INDICATOR:**

- After replacing the filters, press and hold the filter reset button until the indicator light turns off.

**Note:** Regular maintenance includes cleaning the pre-filter every 2-4 weeks and replacing the deodorization and True HEPA filters as indicated by the filter replacement indicator.